



**2DIN Installation / Kit**  
Reference Sheet Summer 2005



Please note: This list is provided as a general reference based on information current 7/1/2005.

MAKE	MODEL	From	To	Metra kit #, mount type, and / or notes
<b>ACURA</b>				
ACURA	CL	1997	1999	99-7801
ACURA	TL	1996	1998	99-7801
ACURA	Integra	1990	2001	99-7801
ACURA	Legend	1990	1996	99-7801
ACURA	RSX (NON TYPE S)	2002	2005	FACTORY BRACKETS
ACURA	Vigor	1991	1996	99-7801
<b>BUICK</b>				
BUICK	Century	1997	2005	99-2003
BUICK	Le Sabre	2000	2003	99-2003
BUICK	Park Avenue	1995	2005	99-2003
BUICK	Rainier	2004	2005	99-2003
BUICK	Regal	1995	2004	99-2003
BUICK	Rendezvous	2002	2005	99-2003
<b>CADILLAC</b>				
CADILLAC	Brougham	1990	1992	99-2003
CADILLAC	EXT	2003	2005	99-2003
CADILLAC	Escalade	2003	2005	99-2003
CADILLAC	Fleetwood (including Brougham)	1993	1996	99-2003
CADILLAC	Fleetwood Brougham	1990	1992	99-2003
<b>CHEVROLET</b>				
CHEVROLET	Avalanche	2003	2005	99-2003
CHEVROLET	Blazer	2003	2005	99-2003
CHEVROLET	Blazer With Double-DIN Radio	2002	2002	99-2003
CHEVROLET	Cavalier	2000	2005	99-2003 (DEPTH IS A PROBLEM, SUB DASH PLASTIC CAN BE CUT)
CHEVROLET	Colorado	2004	2005	99-2003
CHEVROLET	Corvette	1990	1996	99-3051
CHEVROLET	Express van (full size)	2001	2005	99-2003
CHEVROLET	Impala	2000	2005	99-2003
CHEVROLET	Malibu (2004 Classic Style only)	2001	2004	99-2003
CHEVROLET	Monte Carlo	2000	2005	99-2003
CHEVROLET	Prizm	1998	2003	FACTORY BRACKETS
CHEVROLET	S-10 Pickup	2003	2004	99-2003
CHEVROLET	S-10 Pickup With Double-DIN Radio	2002	2002	99-2003
CHEVROLET	Silverado Pickup (all models)	2003	2005	99-2003
CHEVROLET	SSR	2003	2005	99-2003
CHEVROLET	Suburban	2003	2005	99-2003
CHEVROLET	Tahoe	2003	2005	99-2003
CHEVROLET	Trailblazer	2002	2005	99-2003
CHEVROLET	Van (full size) Express	2003	2005	99-2003
CHEVROLET	Venture Van	2000	2005	99-2003
<b>DAEWOO</b>				
DAEWOO	LANOS	1999	2002	FACTORY BRACKETS
DAEWOO	LEGANZA	1999	2002	FACTORY BRACKETS
DAEWOO	NUBIRA	1999	2002	FACTORY BRACKETS
<b>DODGE</b>				
<i>All of the following Dodge and Eagle applications are for vehicles without a dividing bar between the factory radio and factory pocket</i>				
DODGE	Stealth	1990	1996	FACTORY BRACKETS
EAGLE	Talon	1990	1998	FACTORY BRACKETS
<b>FORD</b>				
FORD	Crown Victoria	1995	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Econoline Full Size Van	1997	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Escape	2001	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Excursion	2000	2004	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Expedition	2003	2003	CUSTOM MOUNTING
FORD	Expedition	1997	2002	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Explorer	2002	2003	CUSTOM MOUNTING
FORD	Explorer	1995	2001	99-5805 (WITH MINOR DASH MODS)
FORD	Explorer Sport Trac	2001	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Pickup F-250/350/450/550/650/750	1999	2004	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Pickup F-150	2004	2004	99-5807
FORD	F-150	2004	2005	99-5807
FORD	Freestyle	2005	2005	99-5807
FORD	Five-Hundred	2005	2005	99-5807
FORD	Mustang	2005	2005	99-5807
FORD	Pickup F-150	1997	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
FORD	Mustang	2001	2003	CUSTOM MOUNTING
FORD	Ranger	1995	2005	99-5805
FORD	Windstar	1999	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
<b>GEO For 98 &amp; up see CHEVROLET</b>				
GEO	Spectrum	1989	1989	CUSTOM MOUNTING



**2DIN Installation / Kit**  
Reference Sheet Summer 2005



Please note: This list is provided as a general reference based on information current 7/1/2005.

MAKE	MODEL	From	To	Metra kit #, mount type, and / or notes
GEO	Metro	1995	1997	CUSTOM MOUNTING
GEO	Metro	1992	1994	CUSTOM MOUNTING
GEO	Metro Convertible	1994	1994	CUSTOM MOUNTING
GEO	Metro Convertible	1991	1993	CUSTOM MOUNTING
GEO	Prizm	1993	1997	CUSTOM MOUNTING
GEO	Prizm	1990	1992	CUSTOM MOUNTING
GEO	Prizm	1989	1989	CUSTOM MOUNTING
GEO	Storm	1990	1993	CUSTOM MOUNTING
GEO	Tracker	1992	1997	CUSTOM MOUNTING
<b>GMC</b>				
GMC	Canyon	2004	2005	99-2003
GMC	Denali	2003	2003	99-2003
GMC	Envoy	2002	2005	99-2003
GMC	Sierra	2003	2005	99-2003
GMC	Savana Full Size Van	2003	2005	99-2003
GMC	Sonoma	2003	2003	99-2003
GMC	Sonoma With Double-DIN Radio	2002	2003	99-2003
GMC	Yukon Denali	2003	2005	99-2003
GMC	Yukon / Yukon XL	2003	2005	99-2003
<b>HONDA</b>				
HONDA	Accord	1998	2002	99-7801
HONDA	Accord	1990	1997	99-7801
HONDA	Civic	2001	2005	99-7865
HONDA	Civic	1999	2000	99-7801
HONDA	Civic Si	2002	2005	99-7860
HONDA	CRV	1997	2002	99-7801
HONDA	Element	2003	2005	FACTORY BRACKETS
HONDA	Odyssey	1995	2002	99-7801
HONDA	Passport	1998	2002	FACTORY BRACKETS
HONDA	Prelude	1992	2001	99-7801
<b>HYUNDAI</b>				
HYUNDAI	Elantra	2001	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
HYUNDAI	Elantra w/ double-din opening	1996	2000	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
HYUNDAI	Santa Fe	2001	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
HYUNDAI	Sonata	2002	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
HYUNDAI	Tiburon	2003	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
HYUNDAI	XG 350	2002	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
HYUNDAI	XG 300	2001	2001	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
<b>HUMMER</b>				
HUMMER	H2	2003	2005	99-2003
HUMMER	H2 SUT	2004	2005	99-2003
<b>INFINITI</b>				
INFINITI	ALL MODELS	1995	1999	FACTORY BRACKETS
<b>ISUZU</b>				
ISUZU	Ascender	2003	2005	99-2003
ISUZU	Amigo	1998	2000	FACTORY BRACKETS
ISUZU	Oasis	1996	1999	99-7801
ISUZU	Rodeo	1998	2003	FACTORY BRACKETS
ISUZU	Rodeo Sport	2001	2003	FACTORY BRACKETS
<b>KIA</b>				
KIA	Optima	2001	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
KIA	Rio	2001	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
KIA	Sedona	2002	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
KIA	Sephia	1995	2001	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
KIA	Sorrento	2003	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
KIA	Spectra	2000	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
KIA	Sportage	1995	2003	CUSTOM MOUNTING (FACTORY BRACKETS WORK PARTIALLY)
<b>LEXUS</b>				
LEXUS	IS 300	2001	2005	99-8151
<b>LINCOLN</b>				
LINCOLN	Aviator	2003	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
LINCOLN	Blackwood	2001	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
LINCOLN	Continental	1995	1997	CUSTOM MOUNTING AND MAY NEED DASH MODS
LINCOLN	Mark VIII	1996	1998	CUSTOM MOUNTING AND MAY NEED DASH MODS
LINCOLN	Navigator (late production)	2003	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
LINCOLN	Navigator (early production)	2003	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
LINCOLN	Navigator	1997	2002	CUSTOM MOUNTING AND MAY NEED DASH MODS
LINCOLN	Town Car	1995	2002	CUSTOM MOUNTING AND MAY NEED DASH MODS
<b>MAZDA</b>				
MAZDA	626	2001	2002	99-7505
MAZDA	626	1986	2000	CUSTOM MOUNTING



**2DIN Installation / Kit**  
Reference Sheet Summer 2005



Please note: This list is provided as a general reference based on information current 7/1/2005.

MAKE	MODEL	From	To	Metra kit #, mount type, and / or notes
MAZDA	929	1988	1997	CUSTOM MOUNTING
MAZDA	B-series Pickup	1995	2002	99-5805
MAZDA	Miata	1998	2005	99-7505
MAZDA	Millenia	1995	2002	99-7505
MAZDA	MX6	1986	1992	CUSTOM MOUNTING
MAZDA	Protégé/ Protégé5/ MP3	2001	2004	99-7505
MAZDA	Protege	1990	1994	CUSTOM MOUNTING
MAZDA	Tribute	2001	2005	99-7505
MAZDA	RX7	1986	1997	CUSTOM MOUNTING
<b>MERCEDES</b>				
MERCEDES	C-Class	2001	2003	CUSTOM MOUNTING
MERCEDES	M-Class	1998	2003	CUSTOM MOUNTING
<b>MERCURY</b>				
MERCURY	Grand Marquis	1995	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
MERCURY	Marauder	2003	2003	CUSTOM MOUNTING AND MAY NEED DASH MODS
MERCURY	Montego	2005	2005	99-5807
MERCURY	Mountaineer	2002	2003	CUSTOM MOUNTING
MERCURY	Mountaineer	1997	2001	99-5805
MERCURY	Villager	1996	2002	FACTORY BRACKETS
<b>MITSUBISHI</b>				
<i>All of the following Mitsubishi applications are for vehicles without a dividing bar between the factory radio and factory pocket</i>				
MITSUBISHI	3000GT	1991	1999	FACTORY BRACKETS
MITSUBISHI	Diamante	1992	2003	FACTORY BRACKETS
MITSUBISHI	Eclipse	1989	2003	FACTORY BRACKETS
MITSUBISHI	Expo	1992	1994	FACTORY BRACKETS
MITSUBISHI	Galant	1994	1998	FACTORY BRACKETS
MITSUBISHI	Mirage	1993	2002	FACTORY BRACKETS
MITSUBISHI	Montero	1992	1999	FACTORY BRACKETS
MITSUBISHI	Montero Sport	1997	2003	FACTORY BRACKETS
MITSUBISHI	Outlander	2003	2003	FACTORY BRACKETS
<b>NISSAN</b>				
NISSAN	200SX	1995	1998	FACTORY BRACKETS
NISSAN	240SX	1989	1998	FACTORY BRACKETS
NISSAN	350Z	2003	2005	99-7402
NISSAN	Altima	1993	2001	FACTORY BRACKETS
NISSAN	Armada	2004	2005	99-7406
NISSAN	Frontier	1998	2004	FACTORY BRACKETS
NISSAN	Frontier	2005	2005	99-7581
NISSAN	Hardbody Pickup	1994	1997	FACTORY BRACKETS
NISSAN	Maxima w/o Bose or Comfort pkg	2000	2003	FACTORY BRACKETS
NISSAN	Maxima	1995	1999	FACTORY BRACKETS
NISSAN	Pathfinder SE	2003	2003	FACTORY BRACKETS
NISSAN	Pathfinder	1994	2002	FACTORY BRACKETS
NISSAN	Pathfinder	2005	2005	99-7581
NISSAN	Pulsar	1987	1990	FACTORY BRACKETS
NISSAN	Quest	1996	2003	FACTORY BRACKETS
NISSAN	Sentra	1982	1999	FACTORY BRACKETS
NISSAN	Stanza	1987	1992	FACTORY BRACKETS
NISSAN	Titan	2004	2005	99-7406
NISSAN	Xterra	2000	2004	FACTORY BRACKETS
NISSAN	Xterra	2005	2005	99-7581
<b>OLDSMOBILE</b>				
OLDSMOBILE	Achieva	1996	1998	99-2003
OLDSMOBILE	Alero	1999	2004	99-2003
OLDSMOBILE	Aurora	1995	2003	99-2003
OLDSMOBILE	Bravada	1998	2004	99-2003
OLDSMOBILE	Cutlass	1997	1999	99-2003
OLDSMOBILE	Cutlass Supreme	1995	1997	99-2003
OLDSMOBILE	Eighty-Eight	1994	1999	99-2003
OLDSMOBILE	Intrigue	1998	2002	99-2003
OLDSMOBILE	LSS	1996	1999	99-2003
OLDSMOBILE	Ninety-Eight	1994	1996	99-2003
OLDSMOBILE	Regency	1997	1998	99-2003
OLDSMOBILE	Silhouette	2000	2004	99-2003
<b>PLYMOUTH</b>				
PLYMOUTH	Laser (without dividing bar)	1990	1994	FACTORY BRACKETS
<b>PONTIAC</b>				
PONTIAC	Aztec	2001	2005	99-2003
PONTIAC	Bonneville	2000	2005	99-2003
PONTIAC	Grand Am	2001	2005	99-2003
PONTIAC	Montana	2000	2004	99-2003



**2DIN Installation / Kit**  
Reference Sheet Summer 2005



Please note: This list is provided as a general reference based on information current 7/1/2005.

MAKE	MODEL	From	To	Metra kit #, mount type, and / or notes
PONTIAC	Montana (non SV6)	2005	2005	99-2003
PONTIAC	Sunfire	2000	2005	99-2003
PONTIAC	Vibe	2003	2005	99-8205
<b>SAAB</b>				
SAAB	9-3	1999	2003	CUSTOM MOUNTING
SAAB	9-5	1998	2003	CUSTOM MOUNTING
SAAB	900 Series	1979	1998	CUSTOM MOUNTING
SAAB	9000 Series	1986	1998	CUSTOM MOUNTING
<b>SATURN</b>				
SATURN	ION	2003	2005	99-3106
SATURN	L Series	2000	2005	99-3106
SATURN	S Series	2000	2002	99-3106
SATURN	VUE	2002	2005	99-3106
<b>SUBARU</b>				
SUBARU	BAJA	2003	2005	FACTORY BRACKETS
SUBARU	Forster	1998	2005	FACTORY BRACKETS
SUBARU	Impreza	1993	2005	FACTORY BRACKETS
SUBARU	Impreza/Outback Sport	2000	2005	FACTORY BRACKETS
SUBARU	Impreza/ WRX	2002	2005	FACTORY BRACKETS
SUBARU	Legacy	1995	2003	FACTORY BRACKETS
SUBARU	Legacy Outback	1995	1999	FACTORY BRACKETS
SUBARU	Outback	2000	2003	FACTORY BRACKETS
<b>SUZUKI</b>				
SUZUKI	Aerio 5-door	2002	2002	99-2003
SUZUKI	Aerio sedan	2002	2002	99-2003
SUZUKI	Esteem	1995	2003	99-2003
SUZUKI	Grand Vitara	1999	2002	99-2003
SUZUKI	Sidekick	1992	1998	99-2003
SUZUKI	Swift	1992	1994	99-2003
SUZUKI	Vitara	1999	2004	99-2003
SUZUKI	XL-7	2001	2002	99-2003
<b>TOYOTA</b>				
TOYOTA	Avalon	1995	1999	FACTORY BRACKETS
TOYOTA	Camry	1987	2001	FACTORY BRACKETS
TOYOTA	Celica	1986	1999	FACTORY BRACKETS
TOYOTA	Corolla	1998	2002	FACTORY BRACKETS (LOWER DASH - 88-00-8000 REPLACES RADIO)
TOYOTA	Corolla	1984	1997	FACTORY BRACKETS
TOYOTA	Land Cruiser	1982	2003	FACTORY BRACKETS
TOYOTA	Matrix	2003	2005	99-8205
TOYOTA	MR2	1985	1995	FACTORY BRACKETS
TOYOTA	Paseo	1992	1997	FACTORY BRACKETS
TOYOTA	4 Runner	1996	2002	FACTORY BRACKETS
TOYOTA	Pickup/4 Runner	1984	1995	FACTORY BRACKETS
TOYOTA	Sequoia	2001	2002	FACTORY BRACKETS
TOYOTA	Sienna	1996	2003	FACTORY BRACKETS
TOYOTA	Supra	1983	1998	FACTORY BRACKETS
TOYOTA	T100	1993	1998	FACTORY BRACKETS
TOYOTA	Tacoma	1995	2003	FACTORY BRACKETS
TOYOTA	Tercel	1987	1998	FACTORY BRACKETS
TOYOTA	Tundra	1999	2002	FACTORY BRACKETS
<b>VOLKSWAGEN</b>				
VOLKSWAGEN	Golf	1999	2003	PIONEER AVIC-D1 SLEEVE
VOLKSWAGEN	GTI	1999	2003	PIONEER AVIC-D1 SLEEVE
VOLKSWAGEN	Jetta	1999	2003	PIONEER AVIC-D1 SLEEVE
VOLKSWAGEN	Passat	2000	2003	PIONEER AVIC-D1 SLEEVE
<b>VOLVO</b>				
VOLVO	850 Series	1993	1997	CUSTOM MOUNT
VOLVO	940/960	1994	1997	CUSTOM MOUNT
VOLVO	C70 Convertible	2003	2003	CUSTOM MOUNT
VOLVO	C70	1998	2002	CUSTOM MOUNT
VOLVO	S40	2000	2003	CUSTOM MOUNT
VOLVO	S70	1998	2000	CUSTOM MOUNT
VOLVO	S90/V90	1997	1999	CUSTOM MOUNT
VOLVO	V40	2000	2003	CUSTOM MOUNT
VOLVO	V70	1998	2000	CUSTOM MOUNT