

**CHECKING FIRMWARE VERSION**

Please follow one of the procedures below to see the DVD-V8000's firmware version.

**From the Front Panel:**

- 1) Power ON the player without placing a disc in the tray.
- 2) Press and hold the DISPLAY button for a minimum of two (2) seconds to reveal the firmware version.

**Using the Remote Control:**

- 1) Power ON the player without placing a disc in the tray.
- 2) Press the SETUP button on the remote control.  
*The SETUP menu appears.*
- 3) Select INITIAL SETTINGS, using the arrow buttons to highlight the option.
- 4) Press the ENTER button to confirm the selection.
- 5) Press the DISPLAY button to reveal the current firmware version.

*Firmware Version Chart*

<b>Firmware</b>	<b>Date</b>	<b>Improvements</b>
1.026	July 2004	<i>Initial Release</i>
1.036	Sept 2005	<ol style="list-style-type: none"><li>1) Lock up issue after 14+ hours of continuous menu display corrected</li><li>2) Additional commands now available during a Search (?P, #i, \$A, etc.)</li><li>3) Display correction of the "EEPROM error" message</li></ol>
1.046	June 2006	<ol style="list-style-type: none"><li>1) Slider error corrected (laser pick-up movement routine added to player initialization)</li></ol>

To obtain updates, please contact Pioneer Service at 800/872-4159.