



Preset code list

You should have no problem controlling a component if you find the manufacturer in this list, but please note that there are cases where codes for the manufacturer in the list will not work for the model that you are using. There are also cases where only certain functions may be controllable after assigning the proper preset code.



Liste des codes pré-réglés

Vous devriez pouvoir utiliser sans problème un composant si vous trouvez son numéro dans la liste mais, dans le cas de certains modèles, les codes de marques indiqués dans la liste peuvent ne pas être valides. Dans d'autres cas, seules certaines fonctions agiront bien que le code de pré-réglage approprié ait été saisi.



TV / Téléviseur

General / Ordinaire

Pioneer 10166, 10679, 11260, 11398, 11633
A-Mark 10047, 10054, 10160
A.R. Systems 10556
Accuscan 10047
Admiral 10047, 10054, 10017, 10051, 10093, 10463, 10180
Adventuri 10000
Agna 10150
Aiko 10092
Akai 10812, 11675, 10060, 10702, 10145, 10672
Alba 10037
Alfide 10672
Ambassador 10150
America Action 10180
American High 10000, 10060
Amstrad 10171
Amtron 10000, 10180
Anam 10180
AOC 10180, 11365
Apex Digital 10156, 10765, 10890, 11217
AR 10556
Audinac 10180
Audiovox 10451, 10180, 10092, 10623, 10802, 10875
Aventura 10171
Barco 10556
Baysonic 10180
Beaumarck 10017, 10178
Bell & Howell 10054, 10154, 10093
BenQ 11574
Blue Sky 10556
Bradford 10180
Brockwood 10178
Broksonic 10236, 10463, 10180
Byd:sign 11309
Capehart 10017, 10178, 10092
Carver 10054
CCE 10037
Celebrity 10000
Celera 10765
Changhong 10156, 10765
Cineral 10451, 10092
Citek 10047
Citizen 10000, 10054, 10451, 10463, 10180, 10060, 10171, 10092
Clarion 10180
Classic 10092
Colortyme 10047, 10054, 10017, 10060, 10178
Commercial Solutions 11447, 10047
Conic 10178
Contec 10180
Craig 10180, 10171
Crosley 10000, 10054, 10180, 10171
Crown 10093, 10180, 10672
Crown Mustang 10672

Curtis Mathes 10000, 10047, 10054, 10154, 10051, 10451, 10093, 10180, 10060, 10702, 10178, 10145, 10166, 10037, 11147
CXC 10180
Daewoo 11755, 10451, 10178, 10092, 11661, 10623, 10661, 10672, 11756
Dayton 10092
Daytron 10178, 10092
Dell 11264, 11080, 11178, 11403
Denon 10145
Dumont 10017, 10180, 10178
Durabrand 10463, 10180, 10178, 10171
Dwin 10093
Dynex 11463, 12049
Eaton 10060
Electroband 10000
Electrograph 11755
Electrohome 10000, 10154, 10463, 10150, 10178
Element 11687
Emerald 10178
Emerson 10047, 10017, 10154, 10451, 10236, 10463, 10180, 10150, 10178, 10171, 10623, 11394
Envision 11365
ESA 10812, 10171
Ferguson 10625
Fisher 10000, 10054, 10154
Fortress 10093
Fujitsu 10809, 10683, 10853
Funai 10000, 10180, 10171, 11271
Futuretech 10180
Gateway 11755, 11756
GE 10000, 11447, 10047, 10051, 10451, 10060, 10178, 11147
Gemini 10047
GFM 10171
Gibraltar 10000, 10017
GoldStar 10047, 10054, 10178, 10037
Goodmans 10037
Gradiente 10053
Granada 10037
Grundig 10037, 10672, 10683
Grundy 10180
Grunpy 10180
Haier 11748
Hallmark 10236, 10180, 10178
Hannsprece 11351
Hanseatic 10556
Harley Davidson 10000, 10180, 10060, 10178
Harman/Kardon 10054
Harvard 10180
Heaverm 10093
Healthkit 10017
Helios 10865
Hello Kitty 10451
Hewlett Packard 11494, 11101, 11502

Hitachi 10000, 11643, 10047, 10054, 10017, 10051, 11145, 10145, 11576
HP 11494, 11101, 11502
Hyundai 10865
Ima 10236, 10180, 10178
Infinity 10054
Innova 10037
Insignia 11423, 11564, 10171, 11517, 11710, 12049
Inteq 10017, 10145
JBL 10054
JCB 10000
Jinjing 10037, 10556
JVC 10054, 10053, 10160, 10650, 10731, 11253, 11601, 11633, 11774
Kamp 10017, 10180
KDS 11498, 11687
KEC 10180, 10060
Kenwood 10180
Kioto 10556
KLH 10156, 10180, 10765
Konka 10180
KTV 10463, 10180
Lark 10154
LG 11423, 10054, 10017, 11265, 10060, 10178, 10037, 10856, 11178, 11663, 11768
Lloyd's 10236, 10180
Loewe 10633
Logik 10236, 10180
Lumatron 10037, 10556
LXI 10000, 10047, 10054, 10017, 10154, 10156, 10051, 10093, 10060, 10053, 10178, 10171, 10166, 10037
MAG 11498, 11687
Magnasonic 10000, 10054, 10156, 10093, 10092
Magnavox 10000, 10250, 11454, 11866, 11755, 10047, 10054, 10154, 10051, 10180, 10060, 10171, 10092, 10802, 11254, 11365, 10037
Majestic 10017
Marantz 11454, 10054, 10037, 10556, 10704, 10855, 11398
Mark 10037
Matsui 10037
Matsushita 10250, 10051, 10650
Maxent 11755, 11211, 11756, 11757
Megatron 10047, 10178, 10145
Memorex 10154, 10463, 10180, 10150, 10178, 10037
Mermaid 10037
MGA 10150, 10178
MGN Technology 10178
Micro Genius 10150
Midland 10047, 10017, 10051
Minato 10037, 10556
Mitsubishi 10154, 11250, 10093, 10150, 10178, 10160, 10836
Motorola 10054, 10051, 10093, 10150
MTC 10180, 10060, 10092

Multitech 10180
NAD 10156, 10178, 10166, 10037, 11156
National 10226
NEC 10047, 10178, 10704, 11398, 11704, 11797
NetTV 11755
Nikko 10178, 10092
Nikkodo 10178, 10092
Norcent 11365
NTC 10092
Nyon 10000
Ölevia 11610, 11144, 11240, 11331
Onwa 10180
Optimus 10250, 10154, 10093, 10180, 10150, 10178, 10166, 10650
Optonica 10093
Orion 10017, 10236, 10463, 10180, 10178, 11463
Pace 10092
Pacific 10037, 10556
Panasonic 11480, 10250, 10054, 10156, 10051, 10236, 10226, 10650, 11310, 11636, 11650
Paxonix 10060
PCE 10156, 10060
Penney 10000, 10250, 10047, 10156, 10051, 10060, 10178, 10037
Petters 11523
Philco 10054, 10463, 10145, 10171, 11271, 11394
Philips 11454, 10054, 10171, 10037, 10556, 10605, 10690, 11254, 11506, 11744
Pilot 10051, 10060, 10178
Polaroid 11523, 10765, 10865, 11276, 11314, 11498, 11687, 11766
Portland 10451, 10092
Precision 10236, 10180
Prism 10250, 10051
Proscan 11447, 10047
Protex 10037
Proton 10178
Proview 11498, 11687
ProVision 10037, 10556
Pulsar 10017, 10092
Pulser 10178, 10092
Quartz 10150, 10178
Quasar 10250, 10051, 10650
R-Line 10037
Rabbit 10047
RadioShack 10047, 10154, 10180, 10150, 10178
RCA 10000, 11547, 11447, 10047, 10054, 10051, 10093, 10178, 10090, 10679, 11047, 11147, 11247, 11781, 12187
Realistic 10047, 10154, 10180, 10150, 10178
Revox 10037
Runco 10017, 10060, 11398
Sampo 11755, 10047, 11756

Samsung 10812, 10047, 10054, 10017, 10154, 10060, 10702, 10178, 12051, 11619, 11235, 11060, 10814, 10766, 10650, 10587, 10037
Sanky 10060
Sansui 10463, 10060, 10171
Sanyo 10000, 11755, 10047, 10054, 10154, 10463, 10171, 10037, 11142
Saville 10060
Sceptre 11217, 11360
Scotch 10178
Scott 10236, 10180, 10178
Sears 10000, 10047, 10054, 10017, 10154, 10156, 10051, 10093, 10060, 10053, 10178, 10171, 10166, 10037
Selec 11351
Sharp 10818, 10054, 10093, 10180, 11393
Sheng Chia 10093
Shivaki 10178, 10037, 10556
Siemens 10145
Signature 10047, 10093
Simpson 10178
Singer 10060, 10092
Sky-North 10037
Solar Drape 10000
Sony 10810, 10000, 10017, 10154, 10150, 10053, 11651, 11685
Soundesign 10180, 10178
Spectravision 10156, 10178
Spectronic 11498, 11687
Squareview 10171
SR2000 10154, 10171
SSS 10180
Starlite 10236, 10180
Superscan 10093, 10864
Supreme 10000
SV2000 10054
SVA 10587, 10865
Sylvania 10000, 11864, 10047, 10054, 10154, 10051, 10178, 10171, 10092, 10037, 11271, 11314, 11394
Symphonic 10000, 10180, 10178, 10171
Syntax 11610, 11144, 11240, 11331
Tandy 10093
Tatung 10000, 10051, 10037, 11101, 11756
Teac 10154, 10037
Technics 10250, 10054, 10051, 10226
Techwood 10250, 10051, 10060
Teknika 10054, 10463, 10180, 10150, 10060, 10178, 10092
Telecolor 10017
Telefunken 10702, 10625
Tevion 10037, 10556
Thomas 10047, 10178
Thomson 11447, 10047, 10625
TMK 10236, 10180, 10178
TNCi 10017

Tocom 10156
Toshiba 11524, 10154, 10156, 11256, 10150, 11265, 10060, 11145, 10145, 10166, 10650, 10845, 11156, 11656, 11704
Totevision 10051
Toyomenka 10178
Truotone 10250, 10051
TVS 10463
Ultra 10092
Universal 10047
Universum 10037
V 11755, 10864, 10885, 11756
Victor 10053, 10160
Vidikron 10054, 11398, 11633
Vidtech 10178
Viewsonic 11755, 10857, 10864, 10885
Viking 10060
Viore 10054
Vizio 11758, 11755, 10864, 10885, 11756
Wards 10000, 10047, 10054, 10017, 10154, 10051, 10093, 10236, 10178, 10166, 10037, 11156
Waycon 10156
Welton 10178
Westinghouse 10000, 11712, 10451, 10885, 10889, 10890, 11282, 11577
White Westinghouse 10451, 10236, 10463, 10623, 10889
World 10451, 10236, 10463, 10180
Wyse 11365
XR-1000 10154, 10180, 10171
Yamaha 10650
Zenith 10000, 10812, 11423, 10047, 10017, 10093, 10463, 11265, 10178, 11145, 10145, 10171, 10092, 10037, 10160

Magnavox 11866
Marantz 10704, 11398
Maxent 11755, 11757
Mitsubishi 10836
NEC 11398, 11704
NetTV 11755
Panasonic 11480, 10250, 10650
Philips 10690, 11744
Polaroid 10865, 11276
Runco 11398
Sampo 11755
Samsung 10812, 12051
Sanyo 11142
Sony 10810, 10000
SVA 10865
Sylvania 11271, 11394
Tatung 11101, 11756
Toshiba 10650, 11704
Viewsonic 11755
Vizio 11758, 11756
Zenith 10178

SVA 10587
Sylvania 11864, 10171, 11271, 11314, 11394
Symphonic 10171
Syntax 11610, 11144, 11240, 11331
Toshiba 11524, 10845, 11656
Vidikron 11398
Viewsonic 10857, 10864, 10885
Vizio 11758, 10864, 10885, 11756
Westinghouse 11712, 10885, 10889, 10890, 11282, 11577
Wyse 11365
Zenith 11265

HDTV / Téléviseur Haute définition

Pioneer 10679
Mitsubishi 10150
Olevia 11610
Panasonic 10250, 10650
RCA 11447
Samsung 10812, 10702
Toshiba 11256

Rear Projection TV / Téléviseur à rétroprojection

Akai 10812, 10702
Apex Digital 10765
Hitachi 11145
JVC 11601
Mitsubishi 11250
Panasonic 10250
RCA 11447
Samsung 10812
Sony 10810
Toshiba 10156, 11656

TV/DVD Combination / Combiné Téléviseur/DVD

Akai 11675
Dynex 12049
Emerson 11394
Insignia 12049
Magnavox 11866
Polaroid 11523, 11766
RCA 12187
Sylvania 11864, 11394
Toshiba 11524

TV/VCR Combination / Combiné Téléviseur/ Magnétoscope

America Action 10180
Audiovox 10180
Emerson 10236

Plasma television / Téléviseur à écran plasma

Pioneer 10679, 11260, 11398, 14000, 14001, 14003, 14004
Akai 10812, 11675
Daewoo 10661
Dell 11264
Electrograph 11755
ESA 10812
Fujitsu 10809, 10683, 10853
Funai 11271
Gateway 11755, 11756
Haier 11748
Helios 10865
Hewlett Packard 11502
Hitachi 11643
HP 11502
Insignia 11564
JVC 10731
LG 11423, 10178, 10856

LCD / Écran LCD

Pioneer 11260
Akai 11675
AOC 11365
Apex Digital 10890, 11217
Audiovox 10180, 10802, 10875
Byd:sign 11309
Dell 11264, 11080, 11178
Dynex 12049
Element 11687
Emerson 11394
Envision 11365
Funai 10171
Haier 11748
Hannspree 11351
Hitachi 11643
Insignia 11564, 11517, 11710, 12049
JVC 11601, 11774
LG 11423, 10856, 11178, 11768
Magnavox 11866, 10802, 11365
Marantz 10855
Maxent 11755, 11211, 11757
Mitsubishi 11250
NEC 11797
Norcent 11365
Olevia 11610, 11144, 11240, 11331
Panasonic 11480, 10650
Pettters 11523
Philips 11454, 11744
Polaroid 11523, 11276, 11498, 11687, 11766
RCA 10047, 11781, 12187
Sampo 11755
Samsung 10812, 10766, 10814, 12051
Sanyo 11142
Sceptre 11217, 11360
Sharp 10818, 10093
Sony 10810, 11685
Superscan 10864

DVR/VCR / Enregistreur vidéo numérique/Magnétoscope

General / Ordinaire

Pioneer 20162, 20081, 20042, 20067, 20058, 22306, 22465, 22466, 22467
A-Mark 20037, 20000, 20278
ABS 21972
Accurian 20000
Admiral 20060, 20039
Adventura 20037, 20000
Aiko 20278
Aiwa 20037, 20000
Alba 20278
Alienware 21972
Allegro 20039
America Action 20278
American High 20035, 20081
Amstrad 20000
Anam National 20226
Astra 20035
Audio-Technica 20058
Audiovox 20037, 20278, 20038
Avis 20000
Bell & Howell 20035, 20039, 20000
Broksonic 20348, 21479
Calix 20037
Candle 20037, 20038
Canon 20035
Carver 20035, 20081
CCE 20278
Cineral 20278
Citizen 20035, 20037, 20000, 20278

Classic 20037
ColorTyme 20060, 20035, 20045, 20278
Colt 20000
Craig 20037
Criterion 20000
Crosley 20035, 20081, 20000
Crown 20278
Curtis Mathes 20060, 20035, 20162, 20000, 20278
CyberPower 21972
Daewoo 20037, 20045, 20278
Daytron 20037, 20278
Dell 21972
Denon 20081, 20042
DirectTV 20739
Dual 20000
Durabrand 20039, 20038
Dynatech 20000
Electrohome 20060, 20037, 20000, 20043
Electrographic 20037
Emerex 20032
Emerson 20037, 20000, 20043, 20278, 20348, 21479, 21593
Fisher 20039, 20000
Fuji 20035, 20033
Fujitsu 20000
Funai 20037, 20000, 20278, 21593
Garrard 20000

Gateway 21972
GE 20060, 20035, 20000, 20807
Gemini 20060
Genexxa 20037, 20000, 20278
GFM 21593
Go Video 20614
GoldStar 20035, 20037, 20039, 20000, 20278, 20038
Goodmans 20037, 20081, 20000, 20278
Gradiente 20000
Granada 20081, 20042
Grundig 20081, 20226
Harley Davidson 20000
Harman/Kardon 20081, 20038
Hewlett Packard 21972
Hi-Q 20035, 20000
Hitachi 20035, 20037, 20045, 20000, 20042
Howard Computers 21972
HP 21972
Hughes Network Systems 20739, 20042
Humax 20739
Hush 21972
Hytek 20000
iBUYPOWER 21972
Instant Replay 20035, 20226
Jensen 20067
JVC 20067, 20058, 21162

KEC 20037, 20278
Kenwood 20067, 20038
Kodak 20035, 20037
KTV 20000
LG 20037, 20038
Lifetec 20348
Linksys 21972
Lloyd's 20000, 20038
Loewe 20081
Logik 20000
Lumatron 20278
LXI 20037, 20000, 20042, 20067
Magnasonic 20037, 20000, 20278
Magnavox 20035, 20037, 20039, 20081, 20000, 20226, 20618, 21593
Marantz 20035, 20081, 20038
Marta 20037
Matsui 20037, 20348
Matsushita 20035, 20162, 20081, 21162
Media Center PC 21972
Medion 20348
MEI 20035
Memorex 20035, 20162, 20037, 20039, 20000, 20278, 20348, 21162
Metz 20037
MGA 20060, 20043
Microsoft 21972
Mind 21972
Minolta 20042

Mitsubishi 20060, 20000, 20042, 20067, 20043, 20807
Motorola 20035
MTC 20000
MTX 20000
Multitech 20039, 20000
NAD 20058
NEC 20067, 20038
Nikko 20037, 20278
Nikkodo 20037, 20278
Niveus Media 21972
Northgate 21972
Olympus 20035, 20162, 20226
Onkyo 20222
Optimus 21062, 20035, 20162, 20037, 20000, 20058, 21162
Orion 20000, 20278, 21479
Panama 20035
Panasonic 21062, 20035, 20162, 20000, 20225, 20226, 20614, 20616, 21162, 21244, 21293, 21562
Penney 20035, 20162, 20037, 20081, 20000, 20042, 20067, 20038
Pentax 20042
Philco 20035, 20081, 20000
Philips 20739, 20035, 20162, 20081, 20045, 20000, 20616, 20618
Pilot 20037
Polk Audio 20081
Portland 20278
Presidian 21593
Proscan 20060
Protec 20000
Pulsar 20039, 20278
Quartz 20035
Quasar 20035, 20162, 20226, 21162
RadioShack 20035, 20162, 20037, 20000, 21162
Radix 20037

Randex 20037
RCA 20060, 20035, 20045, 20000, 20042, 20058, 20807, 20880
Realistic 20035, 20162, 20037, 20000, 20278, 21162
ReplayTV 20614, 20616
Recavision 21972
Runco 20039
Samsung 20739, 20060, 20045, 20000, 20038, 21014
Sanky 20039
Sansui 20000, 20067, 21479
Sanyo 20000
Scott 20045, 20043
Sears 20060, 20035, 20162, 20037, 20039, 20033, 20045, 20000, 20042, 20067, 20043, 20058
Sharp 20032, 20000, 20807
Shintom 20039, 20000
Siemens 20037
Signature 20060, 20035, 20037, 20000
Singer 20037
Sonic Blue 20614, 20616
Sony 20032, 20035, 20033, 20000, 20067, 20226, 20636, 21972
Soundmaster 20000
Stack 9 21972
STS 20042
SV2000 20000
SVA 20000
Sylvania 20035, 20081, 20000, 20043, 21593
Symphonic 20000, 21593
Systemax 21972
Tagar Systems 21972
Tandy 20000
Tashiko 20037
Tatung 20081, 20000, 20067

Teac 20000, 20067
Technics 20035, 20162, 20037, 20000
Teknika 20035, 20037, 20000
Thomas 20000
Thomson 20060
Tisonic 20278
Tivo 20739, 20618, 20636, 21996
TMK 20000
TNIX 20037
Toshiba 20045, 20000, 20043, 21972, 21996
Tosonic 20278
Totevision 20037
Touch 21972
Trix 20037
Ultra 20045, 20278
Vector 20045
Vector Research 20038
Victor 20067
Video Concepts 20045
Videomagic 20037
Videosonic 20000
Viewsonic 21972
Villain 20000
Voodoo 21972
Wards 20060, 20035, 20037, 20081, 20033, 20045, 20000, 20042, 20043, 20038, 20058
White Westinghouse 20000, 20278
XR-1000 20035, 20000
Yamaha 20038
Zenith 20037, 20039, 20033, 20000, 20278, 21479
ZT Group 21972

ABS 21972
Alienware 21972
CyberPower 21972
Dell 21972
DirecTV 20739
Gateway 21972
Go Video 20614
Hewlett Packard 21972
Howard Computers 21972
HP 21972
Hughes Network Systems 20739
Humax 20739
Hush 21972
iBUYPOWER 21972
Linksys 21972
Media Center PC 21972
Microsoft 21972
Mind 21972
Niveus Media 21972
Northgate 21972
Panasonic 20614, 20616
Philips 20739, 20618
RCA 20880
ReplayTV 20614, 20616
Samsung 20739
Sonic Blue 20614, 20616
Sony 20636, 21972
Stack 9 21972
Systemax 21972
Tagar Systems 21972
Tivo 20739, 20618, 20636
Toshiba 21972, 21996
Touch 21972
Viewsonic 21972
Voodoo 21972
ZT Group 21972

PVR / Enregistreur vidéo personnel
Pioneer 22306, 22465, 22466, 22467

DVD

General / Ordinaire

Pioneer 30525, 30571, 30142, 30631, 30632, 31460, 31512, 31571, 32442
3D LAB 30503, 30539
A-Trend 30714
Accurian 30675, 31416
Acoustic Solutions 30730
Adcom 31094
AEG 30788
Aiwa 30533, 30641
Akai 30695, 30770, 30899
Alba 30672
Alco 30790
Allegro 30869
Amphion Media Works 30872
Amstrad 30713
AMW 30872
Apex Digital 30533, 30672, 30794, 30796, 30797, 30830, 31004, 31020, 31056, 31061
Arrgo 31023
Audiovox 30790
Awa 30730
BBK 31224
Bel Canto Design 31571
Black Diamond 30713
Blue Parade 30571
Blue Sky 30695, 30713
Brandt 30651
Broksonic 30695, 30868
Bush 30690
California Audio Labs 30490
Cambridge Soundworks 30690
Cat 30789
Celestial 31020
Centrex 30672, 31004
Cinea 30831
CineVision 30869, 31483
Citizen 30695, 31277, 31587, 32116
Clairtone 30571
Clatronic 30788
Coby 30778, 30852, 31086, 31107, 31321, 31351
Craig 30831
Creative 30503, 30539
CyberHome 30714, 30816, 30874, 31023, 31024, 31129, 31502, 31537
Daewoo 30784, 30714, 30770, 30869, 31172
Dansai 30770
Daytek 30872
Decca 30770
Denon 30490, 30634, 31634, 32258
Denver 30778

Diamond 30768
Digitor 31005
Digitrex 30672
Disney 30675, 31270
Dual 30675
Durabrand 30713, 31023
DVD2000 30521
Electrohome 32116
Elta 30690
Emerson 30591, 30675, 30821, 31268
Enterprise 30591
Entivo 30503, 30539
Enzer 30770
ESA 30821, 31268
Firline 30651
Fisher 30670
Funai 30675, 31268, 31334
Gateway 31158
GE 30522, 30815
GFM 30675, 31268
Go Video 30573, 30744, 30741, 30783, 30869, 31044, 31075, 31158, 31304, 31483
GoldStar 30741, 30869
Goodmans 30790
Gradiente 30490, 30651
Grundig 30539, 30775
H & B 30850
Harman/Kardon 30582, 30702
Hello Kitty 30831
HIMAX 30843
Hitachi 30573, 30664, 31247, 31664, 31748
Hiteker 30672
Hoyo 30665
Humax 31500, 31588
Hyundai 30850
iLo 31348, 31472
Initial 31472
Insignia 30675, 31268, 32095, 32428
Integra 30571, 31769, 30627, 31634, 32147
IRT 30783
Jaton 30665
JBL 30702
JMB 30695
JSI 31423
JVC 30558, 30623, 30867, 31164, 31275, 31550
jWin 31051
Kawasaki 30790
Kenwood 30490, 30534
Kiss 30665, 30841
KLH 30790, 31020, 31149

Kloss 30533
Koss 30651, 31061, 31423
Kreisen 31421
Landel 30826
Lasonic 30627, 30789
Lecson 31533
DVD2000 30521
Limit 30768
LiteOn 31058, 31158, 31416, 31656
Loewe 30511, 30741
Logix 30783
Magnasonic 30651, 30675
Magnavox 30503, 30539, 30646, 30675, 30713, 30821, 31140, 31268, 31354, 31472, 31506
Marantz 30503, 30539, 30675
McIntosh 31533, 31273
Medion 30651
Memorex 30695, 30831, 31270
MiCo 30723, 30751
Microsoft 30522, 32083
Minato 30752
Mintek 31472
Mitsubishi 31521, 30521
Monyka 30665
Mustek 30730
Myryad 30894
NAD 30741
Naiko 30770
Nakamichi 31222
NEC 30785, 30869
Next Base 30826
Nintaus 31051
Norcent 30872, 31107
Onkyo 30503, 31769, 30627, 30612, 31612, 31627, 32147
Oppo 30575, 31224, 31525
Optimus 30571
Ortron 30651
Pacific 30768
Palsonic 30672, 30852
Panasonic 30490, 30503, 30571, 30632, 30703, 31010, 31011, 31362, 31462, 31490, 31579, 31641, 31762
Philco 30675, 30690, 30733
Philips 30503, 30539, 32056, 32084, 30646, 30585, 30675, 30713, 30854, 31158, 31260, 31267, 31340, 31354, 31506
PianoDisc 31024
Polaroid 31020, 31061, 31086
Polk Audio 30539
Portland 30770
Presidian 30675

Proceed 30672
Proscan 30522
ProVision 30778
Qwestar 30651
Radionette 30741
RadioShack 30571
Riteo 30665
RCA 30522, 30571, 31769, 30790, 30822, 31022
Realistic 30571
Redstar 30763
Reoc 30752
Rio 30869
Rotel 30623, 31178
Rowa 31004
Saba 30651
Sampo 30752
Samsung 30490, 30573, 30744, 30199, 30820, 30899, 31044, 31075, 31748, 32329
Sansui 30695
Sanyo 30670, 30675, 30695, 31334
Schmartz 32367
Schneider 30783
Schwaiger 30752
Sensory Science 31158
Sharp 30630, 30675, 30752, 31256, 32250
Sherwood 30770
Shinsonic 30533
Singer 30751
Skyworth 30898, 32148
Slim Art 30784
SM Electronic 30690, 30730
Sonic Blue 30573, 30783, 30869
Sony 31533, 30533, 30864, 31033, 31069, 31070, 31431, 31516, 31536
Superscan 30821
Sylvania 30675, 30821, 31268, 32194
Symphonic 30675, 30821, 31268, 31334
TAG McLaren 30894
Tatung 30770
Teac 30571, 30759, 30790
Technics 30490, 30703
Technika 30770
Technosonic 30730
Tejvon 30651
Theta Digital 30571
Thomson 30522, 30511, 30551
Tivo 31503, 31512, 31588
Tokai 30665

Toshiba 30503, 30573, 30539, 31769, 30695, 31045, 31154, 31503, 31510, 31515, 31588, 31608, 32277
Tredex 30843
Unimax 30770
United 30730, 30788
Universum 30591, 30779
Urban Concepts 30503, 30539
V 31064, 31226
Venturer 30790
Vizio 31064, 31226
Xbox 30522, 32083
Yamaha 30490, 30539, 30646, 30545, 30497, 30817
Yamakawa 30665, 30710, 30872
Zenith 30503, 30591, 30741, 30869
Zeus 30784

Blu-ray

Pioneer 30142, 32442
Denon 32258
Insignia 30675, 32428
Integra 32147
LG 30741
Magnavox 30675
Onkyo 32147
Panasonic 31641
Philips 32084
Sharp 32250
Sony 31516
Sylvania 30675

HD-DVD

Integra 31769
LG 30741
Microsoft 32083
Onkyo 31769
RCA 31769
Toshiba 31769, 31515
Xbox 32083

DVD-R

Pioneer 30631, 31460, 31512
Accurian 30675, 31416
Apex Digital 31056
Citizen 32116
Coby 31086
CyberHome 31129, 31502
ElectroHome 32116
Funai 30675, 31334
Gateway 31158
Go Video 30741, 31158, 31304
Humax 31588
iLO 31348
JVC 31164, 31275
Kreisen 31421
LG 30741
LiteOn 31158, 31416
Magnavox 30646, 30675, 31506
Panasonic 30490, 31010, 31011, 31579
Philips 30646, 31340
Polaroid 31086
RCA 30522

Samsung 30490
Sanyo 30670
Sensory Science 31158
Sharp 30675
Sony 31033, 31069, 31070, 31431, 31536
Sylvania 30675
Toshiba 31510, 31588, 32277
Zenith 30741

DVD/PVR Combination / Combiné DVD/ Enregistreur vidéo personnel

Pioneer 30631, 31512
Humax 31500, 31588
LG 30741
Panasonic 30490, 31010, 31011
Philips 31340
RCA 30522
Sharp 31256
Sony 31033, 31069, 31070, 31536
Sylvania 30675
Tivo 31512
Toshiba 31503, 31510, 315889

DVD/VCR Combination / Combiné DVD/ Magnétoscope

Pioneer 31460

Accurian 30675
Allegro 30869
Apex Digital 31061
Broksonic 30695
CineVision 30869, 31483
Daewoo 30869
Emerson 30675
Funai 30675
GFM 30675
Go Video 30744, 30741, 30869, 31044, 31075, 31483
GoldStar 30741
Hitachi 30664
JVC 30867, 31164, 31550
LG 30741
LiteOn 31656
Magnavox 30675
Moremex 30695
Panasonic 31762
Philips 30675, 31267
Polaroid 31061
Presidian 30675
RCA 30522, 30822
Samsung 30820, 31044, 31075
Sansui 30695
Sanyo 30670
Sharp 30630
Sony 30864, 31033, 31069, 31070, 31431
Sylvania 30675
Symphonic 30675
Toshiba 30503
Zenith 30741, 30869

CD

General / Ordinaire

Pioneer 71063, 70032, 71087, 70468, 73468
Aiwa 70157
Arcam 70157
Audio Research 70157
Cairn 70157
California Audio Labs 70029
Cambridge Soundworks 70157
Carver 70157
Curtis Mathes 70032
Denon 70034, 70766
DKK 70000
DMX Electronics 70157
Fisher 70000
Genexxa 70032
Grundig 70157
Harman/Kardon 70100, 70157
Hitachi 70032
Inkel 70157, 70180
Integra 70101
JVC 70032, 70072

Kenwood 70626, 70000, 70029, 70028, 70037
Krell 70157
Linn 70157
Magnavox 70157
Marantz 70626, 70029, 70157, 70180
Matsui 70157
MCS 70029
Memorex 70000, 70032, 70468
Micromega 70157
Miro 70000
Mission 70157
Modulaire 70000, 70032, 70087, 70180, 70468
Myryad 70157
NSM 70157
Onkyo 70868, 71327, 70101, 70102, 70138, 70381, 71322, 71323
Optimus 71063, 70000, 70032, 70037, 70087, 70468
Panasonic 70029, 70388, 70752
Penney 70029
Philips 70626, 70157
Polk Audio 70157

Proton 70157
QED 70157
Quad 70157
Quasar 70029
RadioShack 70000, 70032, 70180, 70468
RCA 70032, 70053, 70468
Realistic 70000, 70032, 70087, 70180, 70468
Revox 70157
Rotel 70157
SAE 70157
Sansui 70000, 70157
Sanyo 70000, 70087
Sharp 70037, 70180
Sherwood 70180
Sonic Frontiers 70157
Sony 70000, 70100, 71364
Sugden 70157
Sylvania 70157
Symphonic 70180
TAG McLaren 70157
Tandy 70032
Teac 70180

Technics 70029
Thule Audio 70157
Victor 70072
Wards 70032, 70157, 70053, 70087
Yamaha 70868, 70036, 71292
Yorx 70000

CD-R

Pioneer 71087
Kenwood 70626
Marantz 70626
Onkyo 71322, 71323
Philips 70626
RCA 70053
Sony 70000, 70100, 71364
Yamaha 71292

MD

Pioneer 71063
Onkyo 70868
Optimus 71063

Satellite Set Top Box / Décodeur satellite

General / Ordinaire

Pioneer 00329, 01308
Akai 00200
Allsat 00200
Amstrad 00847, 01113
Asat 00200
Austar 00642, 00879, 01176
Bell ExpressVu 00775
British Sky Broadcasting 00847
Canal 00853
Chaparral 00216
Crossdigital 01109
DirectTV 01377, 00392, 00566, 00639, 01639, 01142, 00247, 00749, 01749, 00819, 01856, 01076, 01108, 00099, 01109, 01392, 01414, 01442, 01609, 01640
Dish Network System 00775, 01505, 01775
Dishpro 00775, 01505, 01775
Echostar 00775, 01505, 01775
Esat 00879
Expressvu 00775, 01775
Fortec Star 01821
Foxtel 00879
Funai 01377
GE 00566
GOI 00775, 01775
Gradiente 00887
Grundig 00173, 00847
Hitachi 00749, 00819

Houston 00775
HTS 00775, 01775
Hughes Network Systems 01142, 00749, 01749, 01442
Humax 01781, 01790
Indovision 00887
Innova 00099
iSkyB 00887
JVC 00775, 00492, 01775
LG 01414
Magnavox 00722
Marantz 00200
Mitsubishi 00749
Netsat 00099, 00887
Nokia 00723
Omega 00887
Pace 00847, 00887, 01175
Panasat 00879
Panasonic 00247, 00701, 00847
Pansat 01807
Philips 00775, 01142, 00749, 01749, 01076, 00722, 00099, 00200, 00847, 01442
Proscan 00392, 00566
RadioShack 00775, 00566
RCA 00775, 00392, 00566, 01142, 00143, 01291, 01392, 01442
Sagem 00820, 01114
Samsung 01377, 01142, 01276, 01108, 01109, 01442, 01609
Siemens 00173
SKY 00099, 00847, 00887, 01175

Sony 00639, 01639, 00847, 01640
Star 00887
Televisa 00887
Thomson 00392, 00566
Tivo 01142, 01442
Toshiba 00749, 01749, 00790
TPS 00820
UltimateTV 01392, 01640
Uniden 00722
ViewSat 01232
Zenith 01856, 01810

SAT/PVR Combination / Combiné SAT/PVR

Bell ExpressVu 00775
DirectTV 01377, 00392, 00639, 01142, 01076, 00099, 01392, 01442, 01640
Dish Network System 00775, 01505
Dishpro 00775, 01505
Echostar 00775, 01505
Expressvu 00775
Hughes Network Systems 01142, 01442
Philips 01142, 01442
Proscan 00392
RCA 01392
Samsung 01442
Sony 00639, 01640
Tivo 01142, 01442
Zenith 01810

Cable Set Top Box / Décodeur câble

General / Ordinaire

Pioneer 01877, 00877, 00144, 00533,
01021, 01782
A-Mark 00008, 00144
ABC 00237, 00008
Acorn 00237
Action 00237
Active 00237
Amino 01602, 01822
Archer 00237
BCC 00276
Century 00008
Cisco 01877, 00877, 01982
Comcast 01982
Digeo 02187
Director 00476
Fosgate 00276
GE 00144
General Instrument 00476, 00810,
00276

GoldStar 00144
Hitachi 00008
i3 Micro 01602
Insight 00476, 00810
Jerrold 00476, 00810, 00276
Macab 00817
Memorex 00000
Motorola 01376, 00476, 00810,
00276, 01106
Myrio 01602, 01822
Noos 00817
Nova Vision 00008
Novaplex 00008
Ono 01068
Pace 01877, 00877, 00237, 00008,
01060, 01068
Parasonic 00000, 00008, 00144,
00107, 01982
Paragon 00000, 00008, 00525
Penney 00000
Philips 01305, 00317

Pulsar 00000
Quasar 00000
RCA 01256
Regal 00276
Runco 00000
Samsung 00144
Scientific Atlanta 01877, 00877,
00237, 00000, 00008
Sejin 01602
Sony 01006
Sprucer 00144
Supercable 00276
Thomson 01256
Toshiba 00000
United Cable 00276
US Electronics 00276, 00008
Videoway 00000
Zenith 00000, 00525

Cable/PVR Combination / Combiné Câble/PVR

Pioneer 01877
Amino 01822
Cisco 01877, 01982
Comcast 01982
Digeo 02187
General Instrument 00810
Jerrold 00810
Motorola 01376, 00810, 01106
Myrio 01822
Pace 01877, 00237
Panasonic 01982
RCA 01256
Scientific Atlanta 01877
Sony 01006
Supercable 00276
Thomson 01256

Laser Disc Player / Lecteur de disque laser

Pioneer 30241, 32447
Denon 30241
Magnavox 30241
Mitsubishi 30241

Cassette Deck / Platine à cassette

Pioneer 40027, 42446
Aiwa 40029
Carver 40029
Denon 40076
Grundig 40029

Harman/Kardon 40029
JVC 40244
Kenwood 40070
Magnavox 40029
Marantz 40029

Onkyo 40135
Optimus 40027
Philips 40029
Polk Audio 40029
RCA 40027

Sansui 40029
Sony 40243
Wards 40027
Yamaha 40097

Digital Tape / Platine à cassette numérique

Pioneer 40019
Onkyo 40019

Video Accessory / Accessoire vidéo

Pioneer 01010
2Wire 02045
ABS 01272
Accurian 01653
ADB 02586
Alienware 01272
Amino 01481
AT&T 02045
CyberPower 01272
Epson 01563
Gateway 01272
Hewlett Packard 01272

Howard Computers 01272
HP 01272
Hush 01272
iBUYPOWER 01272
Insignia 01415
KoolConnect 01481
LG 01415
Linksys 01272
Magnavox 01563
Media Center PC 01272
Microsoft 02049, 01272
Mind 01272

Motorola 01998, 01363
Niveus Media 01272
Northgate 01272
Panasonic 01120
Philco 01563
Ricavision 01272
Samsung 01190, 01490
Sharp 01010
Sony 01272, 01324
Stack 9 01272
SureWest 01481
Sylvania 01563

Systemax 01272
Tagar Systems 01272
Toshiba 01272
Touch 01272
Viewsonic 01272, 01329
Voodoo 01272
Xbox 02049
Zenith 01415
ZT Group 01272