

Model	Part Number	Description
AVX-P7000CD	CXB4227	DETACHABLE FACE PLATE
DEH-21	CXB4580	DETACHABLE FACE PLATE
DEH-2100	CXB4577	DETACHABLE FACE PLATE
DEH-31	CXB1797	DETACHABLE FACE PLATE
DEH-345	CXB1796	DETACHABLE FACE PLATE
DEH-36	CXB1795	DETACHABLE FACE PLATE
DEH-405	CXA5870	DETACHABLE FACE PLATE
DEH-40DH	CXA6971	DETACHABLE FACE PLATE
DEH-41	CXB2005	DETACHABLE FACE PLATE
DEH-415	CXA6949	DETACHABLE FACE PLATE
DEH-43	CXA9576	DETACHABLE FACE PLATE
DEH-435	CXA9575	DETACHABLE FACE PLATE
DEH-43DH	CXA8453	DETACHABLE FACE PLATE
DEH-445	CXB2004	DETACHABLE FACE PLATE
DEH-45	CXA5869	DETACHABLE FACE PLATE
DEH-45DH	CXA9606	DETACHABLE FACE PLATE
DEH-46	CXB2003	DETACHABLE FACE PLATE
DEH-46DH	CXB3731	DETACHABLE FACE PLATE
DEH-47	CXA6948	DETACHABLE FACE PLATE
DEH-48	CXA9574	DETACHABLE FACE PLATE
DEH-505	CXA5868	DETACHABLE FACE PLATE
DEH-505-W	CXA6799	DETACHABLE FACE PLATE
DEH-50DH	CXA6970	DETACHABLE FACE PLATE
DEH-515	CXA6947	DETACHABLE FACE PLATE
DEH-515-W	CXA7985	DETACHABLE FACE PLATE
DEH-53	CXA9618	DETACHABLE FACE PLATE
DEH-535	CXA9617	DETACHABLE FACE PLATE
DEH-535-W	CXB1214	DETACHABLE FACE PLATE
DEH-53DH	CXA8452	DETACHABLE FACE PLATE
DEH-55DH	CXA7951	DETACHABLE FACE PLATE
DEH-58	CXA9616	DETACHABLE FACE PLATE
DEH-59DH	CXA9605	DETACHABLE FACE PLATE
DEH-635	CXA9613	DETACHABLE FACE PLATE
DEH-65DH	CXA7950	DETACHABLE FACE PLATE
DEH-66DH	CXB3730	DETACHABLE FACE PLATE
DEH-68	CXA9612	DETACHABLE FACE PLATE
DEH-680	CXX1061	DETACHABLE FACE PLATE
DEH-730	CXA5190	DETACHABLE FACE PLATE
DEH-760	CXA3964	DETACHABLE FACE PLATE
DEH-770	CXA3962	DETACHABLE FACE PLATE
DEH-780	CXX1057	DETACHABLE FACE PLATE
DEH-880	CXX1052	DETACHABLE FACE PLATE
DEH-M980	CXX1049	DETACHABLE FACE PLATE
DEH-M990DSP	CXA5108	DETACHABLE FACE PLATE
DEH-P20	CXB3606	DETACHABLE FACE PLATE
DEH-P200	CXB3608	DETACHABLE FACE PLATE
DEH-P2000	CXB3607	DETACHABLE FACE PLATE
DEH-P300	CXB3604	DETACHABLE FACE PLATE
DEH-P3000	CXB3603	DETACHABLE FACE PLATE
DEH-P310	CXB4719	DETACHABLE FACE PLATE
DEH-P400	CXB3600	DETACHABLE FACE PLATE
DEH-P4000	CXB3599	DETACHABLE FACE PLATE
DEH-P41	CXB4713	DETACHABLE FACE PLATE
DEH-P410	CXB4715	DETACHABLE FACE PLATE
DEH-P4100	CXB4714	DETACHABLE FACE PLATE
DEH-P47DH	CXB5396	DETACHABLE FACE PLATE
DEH-P520	CXB4914	DETACHABLE FACE PLATE

Model	Part Number	Description
DEH-P5200	CXB4915	DETACHABLE FACE PLATE
DEH-P545	CXB2001	DETACHABLE FACE PLATE
DEH-P545-W	CXB2810	DETACHABLE FACE PLATE
DEH-P56	CXB2000	DETACHABLE FACE PLATE
DEH-P600	CXB3688	DETACHABLE FACE PLATE
DEH-P6000	CXB3689	DETACHABLE FACE PLATE
DEH-P605	CXA5737	DETACHABLE FACE PLATE
DEH-P615	CXA7250	DETACHABLE FACE PLATE
DEH-P6200	CXB5677	DETACHABLE FACE PLATE
DEH-P625	CXA8151	DETACHABLE FACE PLATE
DEH-P645	CXB1994	DETACHABLE FACE PLATE
DEH-P646	CXB1996	DETACHABLE FACE PLATE
DEH-P65	CXA5743	DETACHABLE FACE PLATE
DEH-P67	CXA7248	DETACHABLE FACE PLATE
DEH-P7000R	CXB3685	DETACHABLE FACE PLATE
DEH-P700R	CXB3684	DETACHABLE FACE PLATE
DEH-P715	CXA7243	DETACHABLE FACE PLATE
DEH-P720	CXB5234	DETACHABLE FACE PLATE
DEH-P7200	CXB5233	DETACHABLE FACE PLATE
DEH-P725	CXA8147	DETACHABLE FACE PLATE
DEH-P725R	CXA9166	DETACHABLE FACE PLATE
DEH-P725-W	CXA8873	DETACHABLE FACE PLATE
DEH-P735	CXA9972	DETACHABLE FACE PLATE ASSY
DEH-P736	CXA9974	DETACHABLE FACE PLATE
DEH-P75DH	CXA9604	DETACHABLE FACE PLATE
DEH-P76DH	CXB3729	DETACHABLE FACE PLATE
DEH-P77DH	CXB5395	DETACHABLE FACE PLATE
DEH-P8000R	CXB3980	DETACHABLE FACE PLATE
DEH-P815	CXA7061	DETACHABLE FACE PLATE
DEH-P8200R	CXB5229	DETACHABLE FACE PLATE
DEH-P825	CXA8201	DETACHABLE FACE PLATE
DEH-P8250	CXB5231	DETACHABLE FACE PLATE
DEH-P835R	CXA9964	DETACHABLE FACE PLATE ASSY
DEH-P835R-W	CXA9952	DETACHABLE FACE PLATE
DEH-P85DHR	CXA9603	DETACHABLE FACE PLATE
DEH-P86DHR	CXB3728	DETACHABLE FACE PLATE
DEH-P900R	CXB3273	DETACHABLE FACE PLATE
DEH-P9200R	CXB5459	DETACHABLE FACE PLATE
DEH-P920R	CXB5456	DETACHABLE FACE PLATE
DEH-P946	CXB2606	DETACHABLE FACE PLATE
DEQ-7550	CXA4849	DETACHABLE FACE PLATE
DEQ-9200	CXA7657	DETACHABLE FACE PLATE
DEX-M300	CXA2239	DETACHABLE FACE PLATE
DEX-M88	CXA3694	DETACHABLE FACE PLATE
DEX-P1	CXB2605	DETACHABLE FACE PLATE
DEX-P1R	CXB2601	DETACHABLE FACE PLATE
DEX-P78	CXA9971	DETACHABLE FACE PLATE
DEX-P88	CXA8146	DETACHABLE FACE PLATE
DEX-P98R	CXA9963	DETACHABLE FACE PLATE
DEX-P99	CXA8202	DETACHABLE FACE PLATE
DPX-M200WC	CXA2550	DETACHABLE FACE PLATE
KE-1900	CXA6899	DETACHABLE FACE PLATE
KEH-1100	CXA8549	DETACHABLE FACE PLATE
KEH-1400	CXA8545	DETACHABLE FACE PLATE
KEH-1500	CXA9867	DETACHABLE FACE PLATE
KEH-1700	CXB1767	DETACHABLE FACE PLATE
KEH-1800	CXB3379	DETACHABLE FACE PLATE
KEH-2403	CXA6629	DETACHABLE FACE PLATE
KEH-2600	CXA6237	DETACHABLE FACE PLATE
KEH-3400	CXA8632	DETACHABLE FACE PLATE

Model	Part Number	Description
KEH-3600	CXA6231	DETACHABLE FACE PLATE
KEH-490	CXA6236	DETACHABLE FACE PLATE
KEH-M4500	CXA4778	DETACHABLE FACE PLATE
KEH-M6500	CXA5153	DETACHABLE FACE PLATE
KEH-M7550	CXA5151	DETACHABLE FACE PLATE
KEH-M8500-W	CXA6041	DETACHABLE FACE PLATE
KEH-M8550	CXA4941	DETACHABLE FACE PLATE ASSY
KEH-P2800	CXB3369	DETACHABLE FACE PLATE
KEH-P3600	CXA9990	DETACHABLE FACE PLATE
KEH-P3700	CXB1723	DETACHABLE FACE PLATE
KEH-P4000	CXA5988	DETACHABLE FACE PLATE
KEH-P404	CXA8627	DETACHABLE FACE PLATE**MISPRINT GO TO CXA8477
KEH-P414	CXB1053	DETACHABLE FACE PLATE
KEH-P414	CXB1054	DETACHABLE FACE PLATE
KEH-P4200	CXA6719	DETACHABLE FACE PLATE
KEH-P424	CXB2446	DETACHABLE FACE PLATE
KEH-P4400	CXA8477	DETACHABLE FACE PLATE**MISPRINT GO TO CXA8627
KEH-P4600	CXB1054	DETACHABLE FACE PLATE ASSY
KEH-P4700	CXB2442	DETACHABLE FACE PLATE
KEH-P4800	CXB3322	DETACHABLE FACE PLATE
KEH-P5000	CXA5978	DETACHABLE FACE PLATE
KEH-P505	CXA8667	DETACHABLE FACE PLATE
KEH-P515	CXB1047	DETACHABLE FACE PLATE
KEH-P5200	CXA6660	DETACHABLE FACE PLATE
KEH-P525	CXB2306	DETACHABLE FACE PLATE
KEH-P5400	CXA8669	DETACHABLE FACE PLATE
KEH-P5600	CXB1048	DETACHABLE FACE PLATE
KEH-P570	CXA5976	DETACHABLE FACE PLATE
KEH-P5700	CXB2445	DETACHABLE FACE PLATE
KEH-P580	CXB3316	DETACHABLE FACE PLATE
KEH-P5800	CXB3317	DETACHABLE FACE PLATE
KEH-P590	CXA6662	DETACHABLE FACE PLATE
KEH-P5900	CXB5356	DETACHABLE FACE PLATE
KEH-P6000	CXA5707	DETACHABLE FACE PLATE
KEH-P6000-W	CXA6820	DETACHABLE FACE PLATE
KEH-P606	CXA8836	DETACHABLE FACE PLATE
KEH-P616	CXB1447	DETACHABLE FACE PLATE
KEH-P6200	CXA6649	DETACHABLE FACE PLATE
KEH-P6200-W	CXA7987	DETACHABLE FACE PLATE
KEH-P6400	CXA8672	DETACHABLE FACE PLATE
KEH-P6600	CXB1448	DETACHABLE FACE PLATE
KEH-P6600-W	CXB1449	DETACHABLE FACE PLATE
KEH-P690	CXB5358	DETACHABLE FACE PLATE
KEH-P7000	CXA5654	DETACHABLE FACE PLATE
KEH-P7200	CXA6637	DETACHABLE FACE PLATE
KEH-P7400	CXA8933	DETACHABLE FACE PLATE
KEH-P7400-W	CXA9248	DETACHABLE FACE PLATE
KEH-P7650	CXB1335	DETACHABLE FACE PLATE
KEH-P770	CXA5653	DETACHABLE FACE PLATE
KEH-P780	CXB3437	DETACHABLE FACE PLATE
KEH-P7800	CXB3438	DETACHABLE FACE PLATE
KEH-P790	CXA6639	DETACHABLE FACE PLATE
KEH-P818R	CXB1330	DETACHABLE FACE PLATE
KEH-P8200	CXA6708	DETACHABLE FACE PLATE
KEH-P8200-W	CXA7995	DETACHABLE FACE PLATE
KEH-P8600R	CXB1331	DETACHABLE FACE PLATE
KEH-P990	CXA6703	DETACHABLE FACE PLATE
KEX-M900	CXA3719	DETACHABLE FACE PLATE,(US)
KEX-M900	CXA3724	DETACHABLE FACE PLATE,(ES)
RS-D2	CXA5719	DETACHABLE FACE PLATE

Model	Part Number	Description
RS-K1	CXA3582	DETACHABLE FACE PLATE COMPLETE

Pioneer Electronics of Canada, Inc.

300 Allstate Parkway

Markham, Ontario Canada

L3R 0P2

Phone number: 905-479-4411

Fax number: 905-946-7425